

# Omniceil® VBM 200F

Automation for SureMed® adherence cards



Improve adherence and patient outcomes today

# The pharmacy of the future

The only automated pharmacy solution that efficiently and accurately fills and checks SureMed® adherence cards. Our new filling machine ensures pharmacies have the competitive advantage to easily scale their business to improve adherence and patient outcomes today.

Compatible  
with most  
UK pharmacy  
interfaces

## Benefits for your business and patients

- improved accuracy and reduced checking time
- ability to track and trace each medication packed
- identifies each drug packed
- adherence cards support patients to live better for longer - improving health outcomes
- small-footprint, ergonomic design that fits through a standard doorway
- ease of access for cleaning and maintenance
- extremely intuitive and easy-to-use interface

## Increase your pharmacy's revenue and decrease your expenses

- free up staff time and reduce your operating costs
- process 35-40 sealed and audited cards per hour
- assemble more packs with less resource
- supports hub and spoke model to improve efficiency and reduce costs



## Barcoding and RFID technology

The system uses barcode and RFID technology to ensure that each pack is audited throughout the entire packing process.

While one pack is being filled by the filling machine, a second pack is staged ready to be filled improving the efficiency and maintaining throughput.



## Uninterrupted workflow and countless cassettes

- capacity to store 200 different medications and countless cassettes in multiple sizes
- cassettes can be exchanged on the machine while it is running which improves filling efficiency
- uses industry standard cassettes available in multiple sizes
- drug specific cassettes with RFID chips for easy identification
- cassette calibration is done in the UK in our dedicated cassette lab in Irlam, Manchester. Ability to calibrate up to 50 cassettes in a turnaround time of one week.\*

## Service and technical support

As an Omnicell customer you will receive excellent service and technical support from day one, including:

- 24/7 helpdesk
- dedicated engineers
- nationwide coverage
- full spare parts
- cassette calibrations done in the UK
- consultancy service provided to guide layout, efficiency and workflow improvements

For further information  
contact us on 0161 413 5333 or  
email [ordersUK@omnicell.com](mailto:ordersUK@omnicell.com)



## Reduce human errors with guided light manual fill packs

Medication that cannot be filled by the system can be staged to be filled manually at the same time as cassette medication. This ensures that all medication is checked via the vision system before placement in the pack decreasing the potential for medication errors.

On screen and guided filling technology directs the operator to the correct drug and correct location within the manual fill station, significantly reducing human error.



## Barcode tracking audit continues at the workstation

Once the pack is filled, traceability is continued with barcode technology at the workstation. Scanning the barcode on the tray triggers the system to print the correct patient card, further improving accuracy of the packaging workflow. The sealing station guides guarantee correct card placement ensuring the most precise alignment with the blisters.

Packed medication images and patient data are visually recorded and stored securely. This data remains easily accessible to pharmacy for reporting and future reference.

## Integration

Integrates with **Omniceil's eMAR solution** - our award winning eMAR solution for care homes that automates the entire medication management and administration process, making it safe, simple and compliant for everyone involved. Both pharmacy and care homes can have complete traceability from the moment medications are dispensed to being administered.

The Omnicell VBM 200F will print a specific barcode on the back of the SureMed blister and the single scan from the Omnicell eMAR system administers all medication against a patient profile making the medication administration process more efficient.

Integrates with leading PIS vendors in the UK.

**Omniceil are the only automation provider** who have integration between two of their own market leading solutions, with the unique link of the barcodes printed on our own high quality consumables - three solutions working together, closing the loop on medication management.

## Improving medication adherence

SureMed® by Omnicell multi-medication adherence cards

Our new filling machine uses bespoke SureMed® Class B certified, weekly pill packs which are designed to improve patient adherence by clearly organising and labelling multiple medications.

Consolidated label with full colour drug images and dosage instructions

Ability to include patient photo as well as details for improved safety.

Easy-to-understand, clearly marked days-of-the-week

**SUREMed**  
by Omnicell  
weekly pill pack max

1122  
Cyrus Patient  
2 Nowhere Street, Irlam, Manchester-M44 2FR  
Omniceil Hub

Omniceil Ltd UK Pharmacy  
Rusland Technology Centre  
Irlam, Manchester  
M44 2FR  
Phone: 0161 4733333

Packed Date: 04/06/2018  
Omniceil Hub  
1168 Street  
HUB City  
HUB 123  
Phone: 01234 567890

PACK 1 of 1

*Class B is a standard of repackaging solid oral medication into a container. The standard assures a dependable barrier against moisture once the container is properly sealed.*



Give your patients the best chance to adhere to medication with SureMed<sup>®</sup> by Omnicell Multimed Blister Cards.



2 Omega Drive River Bend Technology Centre Irlam, M44 5GR  
0161 413 5333 | [ordersUK@omnicell.com](mailto:ordersUK@omnicell.com) | [www.omnicell.com/uk](http://www.omnicell.com/uk)



Omnicell, the Omnicell design mark, OnDemand, Pandora, and RxMap are registered trademarks of Omnicell, Inc. in the United States and internationally. ©2016 All rights reserved. PN950 VBM 200F Tri-Fold Brochure Rev. A 08/16